Waterproof Maintenance Guide

Pre-water inspection and post-saltwater care.



Before water operation

- Inspect seals, covers, connectors and visible damage.
- Confirm aircraft is correctly assembled for the intended environment.

After saltwater exposure

- Follow the exact manufacturer maintenance procedure for your model.
- Do not allow salt residue to remain on the aircraft.
- Inspect propulsion, connectors and corrosion-risk areas before the next flight.

Owner note: These guides are designed to support the owner journey and do not replace the current aircraft manual, manufacturer policy, carrier rules, or applicable aviation requirements.